

LibDsk v1.1.10

John Elliott

18th April 2006

Abstract

LibDsk is a library intended to give transparent access to floppy drives and to the “disc image files” used by emulators to represent floppy drives.

This library is free software, released under the GNU Library GPL. See COPYING for details.

Contents

| | | |
|----------|--|----------|
| 1 | Introduction | 5 |
| 1.1 | About this document | 5 |
| 1.2 | About LibDsk | 5 |
| 1.3 | What's new? | 5 |
| 1.4 | Terms and definitions | 6 |
| 2 | Supported file formats | 6 |
| 3 | Architecture | 7 |
| 3.1 | Logical and physical sectors | 7 |
| 3.1.1 | DSK_GEOMETRY in detail | 8 |
| 4 | LibDsk Function Reference | 9 |
| 4.1 | dsk_open: Open an existing disc image | 9 |
| 4.2 | dsk_creat: Create a new disc image | 10 |
| 4.3 | dsk_close: Close a drive or disc image | 10 |
| 4.4 | dsk_dirty: Read the dirty flag | 10 |
| 4.5 | dsk_pread, dsk_lread : Read a sector | 10 |
| 4.6 | dsk_pwrite, dsk_lwrite: Write a sector | 11 |
| 4.7 | dsk_pcheck, dsk_lcheck: Verify sectors on disc against memory | 11 |
| 4.8 | dsk_pformat, dsk_lformat: Format a disc track | 11 |
| 4.9 | dsk_apform, dsk_alform: Automatic format | 12 |
| 4.10 | dsk_psecid, dsk_lsecid: Read a sector ID. | 12 |
| 4.11 | dsk_ptrackids, dsk_ltrackids: Identify sectors on track. | 13 |
| 4.12 | dsk_rtread: Reserved. | 13 |
| 4.13 | dsk_xread, dsk_xwrite: Low-level reading and writing | 13 |
| 4.13.1 | dsk_xread(), dsk_xwrite(): Deleted data | 13 |
| 4.14 | dsk_lthead, dsk_ptread, dsk_xtread | 14 |
| 4.15 | dsk_lseek, dsk_pseek | 14 |
| 4.16 | dsk_drive_status | 15 |
| 4.17 | dsk_dirty: Has drive been written to? | 15 |
| 4.18 | dsk_getgeom: Guess disc geometry | 15 |
| 4.19 | dg_*geom : Initialise disc geometry from boot sector | 15 |
| 4.20 | dg_stdformat : Initialise disc geometry from a standard LibDsk format. | 16 |
| 4.21 | dsk_*_forcehead: Override disc head | 17 |
| 4.22 | dsk_*_option: Set/get driver option | 17 |
| 4.23 | dsk_option_enum: Get list of driver options | 18 |
| 4.24 | dsk_*_comment: Set comment for disc image | 18 |
| 4.25 | dsk_type_enum | 18 |
| 4.26 | dsk_comp_enum | 19 |
| 4.27 | dsk_drvname, dsk_drvdesc | 19 |
| 4.28 | dsk_compname, dsk_compdesc | 19 |
| 4.29 | dg_ps2ls, dg_ls2ps, dg_pt2lt, dg_lt2pt | 19 |
| 4.30 | dsk_strerror: Convert error code to string | 19 |
| 4.31 | dsk_reportfunc_set / dsk_reportfunc_get | 20 |
| 4.32 | dsk_set_retry / dsk_get_retry | 20 |
| 4.33 | dsk_get_psh | 20 |
| 4.34 | Structure: DSK_FORMAT | 20 |

| | | |
|----------|--|-----------|
| 4.35 | LibDsk errors | 21 |
| 4.36 | Miscellaneous | 22 |
| 5 | Initialisation files | 22 |
| 5.1 | libdiskrc format | 22 |
| 5.1.1 | libdiskrc example | 23 |
| 5.2 | Locating libdiskrc | 23 |
| 5.2.1 | UNIX | 23 |
| 5.2.2 | Win32 | 23 |
| 5.2.3 | Win16 | 23 |
| 5.2.4 | DOS | 24 |
| 6 | Reverse CP/M-FS (rcpmfs) backend | 24 |
| 6.1 | In Use | 24 |
| 6.2 | rcpmfs initialisation file | 24 |
| 6.3 | Bugs | 25 |
| 7 | The CopyQM file format | 25 |
| 7.1 | Introduction | 25 |
| 7.2 | Header | 25 |
| 7.3 | CRC | 26 |
| 7.4 | Image comment | 26 |
| 7.5 | Image data | 26 |
| 8 | LibDsk under Windows | 26 |
| 8.1 | Windows 3.x | 27 |
| 8.2 | Windows 4.x (95, 98 and ME) | 27 |
| 8.3 | Windows NT (NT 3.x, NT 4.x, 2000, XP) without ntwdm driver | 27 |
| 8.4 | Windows 2000 and XP with ntwdm driver | 27 |
| 8.5 | General comments on programming floppy access for Windows | 27 |
| 8.5.1 | The Win16 driver. | 27 |
| 8.5.2 | The Win32c driver. | 28 |
| 8.5.3 | The Win32 driver. | 28 |
| 8.5.4 | The ntwdm driver. | 28 |
| 8.5.5 | Other floppy APIs | 28 |
| 8.6 | LDSEVER | 28 |
| 8.6.1 | Compiling LDSEVER | 28 |
| 8.6.2 | Using LDSEVER | 29 |
| 8.6.3 | Important Security Warning | 29 |
| 8.7 | LibDsk and COM | 29 |
| 8.7.1 | General points | 29 |
| 8.7.2 | Library | 29 |
| 8.7.3 | Geometry | 30 |
| 8.7.4 | Disk | 31 |
| 8.7.5 | IReporter | 32 |
| 9 | LibDsk RPC system | 32 |
| 9.1 | The 'serial' driver | 32 |
| 9.1.1 | Servers for the serial driver | 33 |
| 9.2 | The 'fork' driver | 33 |

| | |
|--|-----------|
| 10 Writing new drivers | 34 |
| 10.1 The driver header | 34 |
| 10.2 The driver source file | 34 |
| 10.3 Driver functions | 35 |
| 10.3.1 dc_open | 35 |
| 10.3.2 dc_creat | 36 |
| 10.3.3 dc_close | 36 |
| 10.3.4 dc_read | 36 |
| 10.3.5 dc_write | 36 |
| 10.3.6 dc_format | 36 |
| 10.3.7 dc_getgeom | 36 |
| 10.3.8 dc_secid | 37 |
| 10.3.9 dc_xseek | 37 |
| 10.3.10 dc_xread, dc_xwrite | 37 |
| 10.3.11 dc_status | 37 |
| 10.3.12 dc_tread | 38 |
| 10.3.13 dc_xtread | 38 |
| 10.3.14 dc_option_enum | 38 |
| 10.3.15 dc_option_set, dc_option_get | 38 |
| 10.3.16 dc_trackids | 38 |
| 10.3.17 dc_rtread | 38 |
| 11 Adding new compression methods | 39 |
| 11.1 Driver header | 39 |
| 11.2 Driver implementation | 39 |
| 11.3 Compression functions | 40 |
| 11.3.1 cc_open | 40 |
| 11.3.2 cc_creat | 40 |
| 11.3.3 cc_commit | 41 |
| 11.3.4 cc_abort | 41 |
| 12 Adding new remote transports. | 41 |
| 12.1 Driver header | 41 |
| 12.2 Driver implementation | 41 |
| 12.3 Remote communication functions | 42 |
| 12.3.1 rc_open | 42 |
| 12.3.2 rc_close | 42 |
| 12.3.3 rc_call | 43 |
| A DQK Files | 43 |
| B LibDsk with cpmtools | 44 |
| C DSK / EDSK recording mode extension | 44 |

1 Introduction

1.1 About this document

This document only covers LibDsk – the library – itself. For information on the example utilities supplied with LibDsk (apriboot, dskform, dsktrans, dskid, dskdump, dskscan, dskutil and md3serial) see their respective manual pages.

1.2 About LibDsk

LibDsk is a library for accessing floppy drives and disc images transparently. It currently supports the following disc image formats:

- Raw “dd if=foo of=bar” images;
- CPCEMU-format .DSK images (normal and extended);
- MYZ80-format hard drive images;
- CFI-format disc images, as produced by FDCOPY.COM under DOS and used to distribute some Amstrad system discs;
- ApriDisk-format disc images, used by the utility of the same name under DOS.
- NanoWasp-format disc images, used by the eponymous emulator.
- The floppy drive under Linux;
- The floppy drive under Windows. Windows support is a complicated subject - see section 8 below.
- The floppy drive (and hard drive partitions) under DOS.

LibDsk also supports compressed disc images in the following formats:

- Squeeze (Huffman coded)
- GZip (Deflate)
- BZip2 (Burrows-Wheeler; support is read-only)

1.3 What’s new?

For full details, see the file ChangeLog.

- Added a new driver: “int25”. This allows the DOS version to run on Apricot PCs (which do not have an IBM-compatible BIOS) and to access hard drive partitions.
- Bugfix in the Linux floppy driver, which could cause “No data” errors logging in certain disc formats.
- Bugfix in the rcpmfs driver: Files saved to user 1 no longer go to user 0.
- Enhanced the ApriDisk driver to handle disc images that start with a ‘creator’ block.

- Enhanced the rcpmfs driver to deal with truncation of existing files.
- Added initial support for 'multiple/weak' sectors in the 'dsk' driver. LibDsk can read such sectors, but not write them (they get written as normal sectors).
- Bug fix: Don't leak file handles in the 'dsk' driver.
- The internal RPC system has been expanded to allow operation over a serial line.
- The Win32 (VC++ 6) version now includes an ATL project to present LibDsk as a COM object.
- 'ntwdm' driver added by Simon Owen.
- dsk_dirty() function added by Philip Kendall.
- LibDsk now reads a 'libdskrc' file (section 5.1) at startup; this can contain additional format definitions.
- An experimental read-only driver to handle CopyQM disc images (written by Per Ola Ingvarsson, who also documented the file format - section 7).
- Experimental support for an 'rcpmfs' driver (section 6) which presents directories as CP/M disk images.
- DSK files now store density and recording mode.
- LibDsk can now retry failed reads/writes/formats.
- Extra functions have been added to support disc images that contain comments.
- Extra functions have been added for display of messages from LibDsk.
- A driver has been added for the disc image files used by the ApriDisk utility.
- The parameter order of the example utilities has been made less rigid.

1.4 Terms and definitions

In this document, I use the word CYLINDER to refer to a position on a floppy disc, and TRACK to refer to the data within a cylinder on one side of the disc. For a single-sided disc, these are the same; for a double-sided disc, there are twice as many tracks as cylinders.

2 Supported file formats

The following disc image file formats are supported by LibDsk.

“dsk” : Disc image in the DSK format used by CPCEMU. The format of a .DSK file is described in the CPCEMU documentation.

“edsk” : Disc image in the extended CPCEMU DSK format.

“raw” : Raw disc image - as produced by “dd if=/dev/fd0 of=image”. On systems other than Linux, DOS or Windows, this is also used to access the host system's floppy drive.

- “floppy”** : Host system’s floppy drive (under Linux, DOS or Windows).
- “int25”** : Hard drive partition under DOS. Also used for the floppy drive on Apricot PCs.
- “ntwdm”** : Enhanced floppy support under Windows 2000 and XP, using an additional kernel-mode driver.
- “myz80”** : MYZ80 hard drive image, which is *nearly* the same as “raw” but has a 256 byte header.
- “cfi”** : Compressed floppy image, as produced by FDCOPY.COM under DOS. Its format is described in [cfi.html](#).
- “qm”** : Disc images created by Sydex’s CopyQM. This is a read-only driver.
- “nanowasp”** : Disc image in the 400k Microbee format used by the NanoWasp emulator. This is similar to “raw”, but the tracks are stored in a different order. LibDsk also applies a sector skew so that the sectors are read/written in the logical order. Strictly speaking, it should not do this (when libdsk is used with cpmtools, cpmtools is the one that does the skewing) but cpmtools cannot handle the skewing scheme used by the Microbee format.
- “apridisk”**: Disc image in the format used by the ApriDisk utility. The format is described in [apridisk.html](#).
- “rcpmfs”**: Reverse CP/M filesystem. A directory is made to appear as a CP/M disk. This is an experimental system and should be approached with caution.
- “remote”**: Remote LibDsk server, most likely at the other end of a serial line.

3 Architecture

LibDsk is composed of a fixed core (files named `dsk*.c`) and a number of drivers (files named `drv*.c`). When you open an image or a drive (using `dsk_open()` or `dsk_creat()`) then a driver is chosen. This driver is then used until it’s closed (`dsk_close()`).

Each driver is identified by a name. To get a list of available drivers, use `dsk_type_enum()`. To get the driver that is being used by an open DSK image, use `dsk_drvname()` or `dsk_drvdesc()`.

3.1 Logical and physical sectors

LibDsk has two models of disc geometry. One is as a linear array of “logical” sectors - for example, a 720k floppy appears as 1440 512-byte sectors numbered 0 to 1439. The other locates each sector using a (Cylinder, Head, Sector) triple - so on the 720k floppy described earlier, sectors would run from (0,0,1) to (79,1,9).

Internally, all LibDsk drivers are written to use the Cylinder/Head/Sector model. For those calls which take parameters in logical sectors, LibDsk uses the information in a `DSK_GEOMETRY` structure to convert to C/H/S. `DSK_GEOMETRY` also contains information such as the sector size and data rate used to access a given disc.

Those functions which deal with whole tracks (such as the command to format a track) use logical tracks and (cylinder,head) pairs instead. To initialise a DSK_GEOMETRY structure, either:

- call `dsk_getgeom()` to try and detect it from the disc; or
- call `dg_stdformat()` to select one of the “standard” formats that LibDsk knows about; or
- call `dg_dosgeom()` / `dg_cpm86geom()` / `dg_pcwgeom()` / `dg_aprigeom()` to initialise it from a copy of a DOS / CP/M86 / PCW / Apricot boot sector; or
- Set all the members manually.

3.1.1 DSK_GEOMETRY in detail

```
typedef struct
{
    dsk_sides_t dg_sidedness; /* This describes the logical sequence of tracks
        on the disc - the order in which their host system reads them. This will only be
        used if dg_heads is greater than 1 (otherwise all the methods are equivalent)
        and you are using functions that take logical sectors or tracks as parameters. It
        will be one of:

        SIDES_ALT The tracks are ordered Cylinder 0 Head 0; C0H1; C1H0; C1H1;
        C2H0; C2H1 etc. This layout is used by most PC-hosted operating systems,
        including DOS and Linux. Amstrad's 8-bit operating systems also use this
        ordering.

        SIDES_OUTBACK The tracks go out to the edge on Head 0, and then back in
        on Head 1 (so Cylinder 0 Head 0 is the first track, while Cylinder 0 Head
        1 is the last). This layout is used by Freek Heite's 144FEAT driver (for
        CP/M-86 on the PC) but I have not seen it elsewhere.

        SIDES_OUTOUT The tracks go out to the edge on Head 0, then out again on
        Head 1 (so the order goes C(last)H0, C0H1, C1H1, ..., C(last)H1). This
        ordering is used by Acorn-format discs.

        */

    dsk_p cyl_t dg_cylinders; /* The number of cylinders this disc has. Usually
        40 or 80. */

    dsk_p head_t dg_heads; /* The number of heads (sides) the disc has. Usually
        1 or 2. */

    dsk_p sect_t dg_sectors; /* The number of sectors per track. */

    dsk_p sect_t dg_secbase; /* The first physical sector number. Most systems
        start numbering their sectors at 1; Acorn systems start at 0, and Amstrad CPCs
        start at 65 or 193. */

    size_t dg_secsize; /* Sector size in bytes. Note that several drivers rely on
        this being a power of 2. */
}
```



```

dsk_rate_t dg_datarate; /* Data rate. This will be one of:

    RATE_HD High-density disc (1.4Mb or 1.2Mb)
    RATE_DD Double-density disc in 1.2Mb drive (ie, 360k disc in 1.2Mb drive)
    RATE_SD Double-density disc in 1.4Mb or 720k drive
    RATE_ED Extra-density disc (2.8Mb) */

dsk_gap_t dg_rwgap; /* Read/write gap length */

dsk_gap_t dg_fmtgap; /* Format gap length */

int dg_fm; /* Set to nonzero to use FM (single density) recording mode. Not all
PC floppy controllers support this mode; the National Semiconductor PC87306
and the Future Domain TMC series SCSI controllers can at least read FM discs.
The BBC Micro used FM recording for its 100k and 200k DFS formats. The
Windows / DOS floppy drivers do not support FM recording. */

int dg_nomulti; /* Set to nonzero to disable multitrack mode. This only affects
attempts to read normal data from tracks containing deleted data (or vice versa).
*/

int dg_noskip; /* Set to nonzero to disable skipping deleted data when searching
for non-deleted data (or vice versa). */

} DSK_GEOMETRY;

```

4 LibDsk Function Reference

4.1 dsk_open: Open an existing disc image

```
dsk_err_t dsk_open(DSK_PDRIVER *self, const char *filename, const char *type)
```

Enter with:

- “self” is the address of a DSK_PDRIVER variable (treat it as a handle to a drive / disc file). On return, the variable will be non-null (if the operation succeeded) or null (if the operation failed).
- “filename” is the name of the disc image file. On DOS and Windows, “A:” and “B:” refer to the two floppy drives. On Apricot MS-DOS, “0:” and “1:” refer to the floppy drives.
- “type” is NULL to detect the disc image format automatically, or the name of a LibDsk driver to force that driver to be used. See `dsk_type_enum()` below.
- “compress” is NULL to auto-detect compressed files, or the name of a LibDsk compression scheme. See `dsk_comp_enum()`.

Returns: A `dsk_err_t`, which will be 0 (`DSK_ERR_OK`) if successful, or a negative integer if failed. See `dsk_strerror()`. The error `DSK_ERR_NOTME` means either that no driver was able to open the disc / disc image (if “type” was NULL) or that the requested driver could not open the file (if “type” was not NULL).

Standard LibDsk drivers are listed in section 2.

Compression schemes are:

“sq” : Huffman (squeezed). The reason for the inclusion of this system is to support .DQK images (see appendix A).

“gz” : GZip (deflate). This will only be present if libdsk was built with zlib support.

“bz2” : BZip2 (Burrows-Wheeler compression). This support is currently read-only, and will only be present if LibDsk was built with bzip support.

4.2 dsk_creat: Create a new disc image

```
dsk_err_t dsk_creat(DSK_PDRIVER *self, const char *filename, const char *ty
```

In the case of floppy drives, this acts exactly as `dsk_open()`. For image files, the file will be deleted and recreated. Parameters and results are as for `dsk_open()`, except that “type” cannot be NULL (it must specify the type of disc image to be created) and if “compress” is NULL, it means that the file being created should not be compressed.

4.3 dsk_close: Close a drive or disc image

```
dsk_err_t dsk_close(DSK_PDRIVER *self)
```

Pass the address of an opaque pointer returned from `dsk_open()` / `dsk_creat()`. On return, the drive will have been closed and the pointer set to NULL.

4.4 dsk_dirty: Read the dirty flag

```
int dsk_dirty(DSK_PDRIVER self)
```

This function returns non-zero if the disc has been modified since it was inserted into the drive, and zero if it has not been modified.

4.5 dsk_pread, dsk_lread : Read a sector

```
dsk_err_t dsk_pread(DSK_PDRIVER self, const DSK_GEOMETRY *geom, void *buf,  
dsk_err_t dsk_lread(DSK_PDRIVER self, const DSK_GEOMETRY *geom, void *buf,
```

These functions read a single sector from the disc. There are two of them, depending on whether you are using logical or physical sector addresses.

Enter with:

- “self” is a handle to an open drive / image file.
- “geom” points to the geometry for the drive.

- “buf” is the buffer into which data will be loaded.
- “cylinder”, “head” and “sector” (dsk_pread) or “sector” (dsk_lread) give the location of the sector.

Returns:

- If successful, DSK_ERR_OK. Otherwise, a negative DSK_ERR_* value.
- If the driver cannot read sectors, DSK_ERR_NOTIMPL will be returned.

4.6 dsk_pwrite, dsk_lwrite: Write a sector

```
dsk_err_t dsk_pwrite(DSK_PDRIVER self, const DSK_GEOMETRY *geom, const void *buf,
dsk_err_t dsk_lwrite(DSK_PDRIVER self, const DSK_GEOMETRY *geom, const void *buf,
```

As dsk_pread / dsk_lread, but write their buffers to disc rather than reading them from disc. If the driver cannot write sectors, DSK_ERR_NOTIMPL will be returned.

4.7 dsk_pcheck, dsk_lcheck: Verify sectors on disc against memory

```
dsk_err_t dsk_pcheck(DSK_PDRIVER self, const DSK_GEOMETRY *geom, const void *buf,
dsk_err_t dsk_lcheck(DSK_PDRIVER self, const DSK_GEOMETRY *geom, const void *buf,
```

As dsk_pread / dsk_lread, but rather than reading their buffers from disc, they compare the contents of their buffers with the data already on the disc. If the data match, the functions return DSK_ERR_OK. If there is a mismatch, they return DSK_ERR_MISMATCH. In case of error, other DSK_ERR_* values are returned. If the driver cannot read sectors, DSK_ERR_NOTIMPL will be returned.

4.8 dsk_pformat, dsk_lformat: Format a disc track

```
dsk_err_t dsk_pformat(DSK_PDRIVER self, DSK_GEOMETRY *geom, dsk_p cyl_t cyl,
dsk_err_t dsk_lformat(DSK_PDRIVER self, DSK_GEOMETRY *geom, dsk_ltrack_t track,
```

Enter with:

- “self” is a handle to an open drive / image file.
- “geom” points to the geometry for the drive. The formatter may modify this if (for example) it’s asked to format track 41 of a 40-track drive.
- “cylinder” / “head” (dsk_pformat) or “track” (dsk_lformat) give the location of the track to format.
- “format” should be an array of (geom->dg_sectors) DSK_FORMAT structures. These structures must contain sector headers for the track being formatted. For example, to format the first track of a 720k disc, you would pass in an array of 9 such structures: { 0, 0, 1, 512 }, { 0, 0, 2, 512, } ..., { 0, 0, 9, 512 }

- “filler” should be the filler byte to use. Currently the Win32 driver ignores this parameter. If the driver cannot format tracks, DSK_ERR_NOTIMPL will be returned.

Note that when formatting a .DSK file that has more than one head, you must format cylinder 0 for each head before formatting other cylinders.

4.9 dsk_apform, dsk_alform: Automatic format

```
dsk_err_t dsk_apform(DSK_PDRIVER self, const DSK_GEOMETRY *geom, dsk_pcyln_t
dsk_err_t dsk_alform(DSK_PDRIVER self, const DSK_GEOMETRY *geom, dsk_ltrack
```

These function calls behave as `dsk_pformat()` and `dsk_lformat()` above, except that the sector headers are automatically generated. This saves time and trouble setting up sector headers on discs with standard layouts such as DOS, PCW or Linux floppies. If the driver cannot format tracks, DSK_ERR_NOTIMPL will be returned.

4.10 dsk_psecid, dsk_lsecid: Read a sector ID.

```
dsk_err_t dsk_psecid(DSK_PDRIVER self, const DSK_GEOMETRY *geom, dsk_pcyln_t
dsk_err_t dsk_lsecid(DSK_PDRIVER self, const DSK_GEOMETRY *geom, dsk_ltrack
```

Read a sector ID from the given track. This can be used to probe for discs with oddly-numbered sectors (eg, numbered 65-74). Enter with:

- “self” is a handle to an open drive / image file.
- “geom” points to the geometry for the drive.
- “cylinder” / “head” (`dsk_psecid`) or “track” (`dsk_lsecid`) give the location of the track to read the sector from.
- “result” points to an uninitialised DSK_FORMAT structure.

On return:

- If successful, the buffer at “result” will be initialised with the sector header found, and DSK_ERR_OK will be returned.
- If the driver cannot provide this functionality (for example, the Win32 driver under NT), DSK_ERR_NOTIMPL will be returned.

Note that the DOS, Win16 and Win32 (under Win9x) drivers implement a limited version of this call, which will work on normal DOS / CP/M86 / PCW discs and CPC discs. However it will not be usable for other purposes.

4.11 dsk_ptrackids, dsk_ltrackids: Identify sectors on track.

```
dsk_err_t dsk_ptrackids(DSK_PDRIVER self, const DSK_GEOMETRY *geom, dsk_ptrackids_t result,
dsk_err_t dsk_ltrackids(DSK_PDRIVER self, const DSK_GEOMETRY *geom, dsk_ltrackids_t result,
```

These functions are intended to read all the sector IDs from a track, in order, and (preferably) starting at the index hole. If they succeed, 'result' will point at an array of DSK_FORMAT structures describing the sectors found. This array will have been allocated with dsk_malloc() and should be freed with dsk_free().

4.12 dsk_rtread: Reserved.

```
dsk_err_t dsk_rtread(DSK_PDRIVER self, const DSK_GEOMETRY *geom, void *buf,
```

This function is reserved for future expansion. The intention is to use it for diagnostic read commands (such as reading the raw bits from a track). Currently it returns DSK_ERR_NOTIMPL.

4.13 dsk_xread, dsk_xwrite: Low-level reading and writing

```
dsk_err_t dsk_xread(DSK_PDRIVER self, const DSK_GEOMETRY *geom, void *buf,
dsk_err_t dsk_xwrite(DSK_PDRIVER self, const DSK_GEOMETRY *geom, const void *buf,
```

dsk_xread() and dsk_xwrite() are extended versions of dsk_pread() and dsk_pwrite(). They allow the caller to read/write sectors whose sector ID differs from the physical location of the sector, or to read/write deleted data.. The "cylinder" and "head" arguments specify where to look; the "cyl_expected" and "head_expected" are the values to search for in the sector header.

These functions are only supported by the CPCEMU driver, the Linux floppy driver and the NTWDM floppy driver. Other drivers will return DSK_ERR_NOTIMPL. Unless you are emulating a floppy controller, or you need to read discs that contain deleted data or misnumbered sectors, it should not be necessary to call these functions.

4.13.1 dsk_xread(), dsk_xwrite(): Deleted data

The "deleted" argument is used if you want to read or write sectors that have been marked as deleted. In dsk_xwrite(), this is a simple value; pass 0 to write normal data, or 1 to write deleted data. In dsk_xread(), pass the address of an integer containing 0 (read normal data) or 1 (read deleted data). On return, the integer will contain:

- If the requested data type was read: 0
- If the other data type was read: 1
- If the command failed: Value is meaningless.

Passing NULL acts the same as passing a pointer to 0.

The opposite type of data will only be read if you set geom->dg_noskip to nonzero. Some examples:

| geom->dg_noskip | deleted | Data on disc | Results | *deleted becomes |
|-----------------|---------|--------------|----------------|------------------|
| 0 | -> 0 | Normal | DSK_ERR_OK | 0 |
| 0 | -> 0 | Deleted | DSK_ERR_NODATA | ?? |
| 0 | -> 1 | Deleted | DSK_ERR_NODATA | ?? |
| 1 | -> 0 | Normal | DSK_ERR_OK | 0 |
| 1 | -> 0 | Deleted | DSK_ERR_OK | 1 |
| 1 | -> 1 | Normal | DSK_ERR_OK | 1 |
| 1 | -> 1 | Deleted | DSK_ERR_OK | 0 |

4.14 dsk_lread, dsk_ptread, dsk_xtread

```

dsk_err_t dsk_lread(DSK_PDRIVER self, const DSK_GEOMETRY *geom, void *buf,
dsk_err_t dsk_ptread(DSK_PDRIVER self, const DSK_GEOMETRY *geom, void *buf,
dsk_err_t dsk_xtread(DSK_PDRIVER self, const DSK_GEOMETRY *geom, void *buf,

```

These functions read a track from the disc, using the FDC's "READ TRACK" command. There are three of them - logical, physical and extended physical.

If the driver does not support this functionality, LibDsk will attempt to simulate it using multiple sector reads.

Enter with:

- "self" is a handle to an open drive / image file.
- "geom" points to the geometry for the drive.
- "buf" is the buffer into which data will be loaded.
- "cylinder" and "head" (dsk_ptread, dsk_xtread) or "track" (dsk_lread) give the location of the track to read.
- (dsk_xtread) "cyl_expected" and "head_expected" are used as the values to search for in the sector headers.

Returns:

- If successful, DSK_ERR_OK. Otherwise, a negative DSK_ERR_* value.
- (dsk_xtread() only) If the driver does not support extended sector reads/writes, then DSK_ERR_NOTIMPL will be returned.

4.15 dsk_lseek, dsk_pseek

```

dsk_err_t dsk_lseek(DSK_PDRIVER self, const DSK_GEOMETRY *geom, dsk_ltrack_t
dsk_err_t dsk_pseek(DSK_PDRIVER self, const DSK_GEOMETRY *geom, dsk_pcyl_t

```

Seek to a given cylinder. Only the CPCEMU driver, the Linux floppy driver and the NTWDM floppy driver support this; other drivers return DSK_ERR_NOTIMPL. You should not normally need to call these functions. They have been provided to support programs that emulate a uPD765A controller.

4.16 dsk_drive_status

```
dsk_err_t dsk_drive_status(DSK_PDRIIVER self, const DSK_GEOMETRY *geom, dsk_
```

Get the drive's status (ready, read-only etc.). The byte "result" will have one or more of the following bits set:

DSK_ST3_FAULT: Drive fault

DSK_ST3_RO: Read-only

DSK_ST3_READY: Ready

DSK_ST3_TRACK0: Head is over track 0

DSK_ST3_DSDDRIIVE: Drive is double-sided

DSK_ST3_HEAD1: Current head is head 1, not head 0. Usually this just depends on the value of the "head" parameter to this function.

Which bits will be "live" depends on which driver is in use, but the most trustworthy will be DSK_ST3_READY and DSK_ST3_RO. This function will never return DSK_ERR_NOTIMPL; if the facility is not provided by the driver, a default version will be used.

4.17 dsk_dirty: Has drive been written to?

```
int dsk_dirty(DSK_PDRIIVER self);
```

This returns zero if the disc has not been written to since it was opened, nonzero if it has.

4.18 dsk_getgeom: Guess disc geometry

```
dsk_err_t dsk_getgeom(DSK_PDRIIVER self, DSK_GEOMETRY *geom)
```

This attempts to determine the geometry of a disc (number of cylinders, tracks, sectors etc.) by loading the boot sector. It understands DOS, Apricot, CP/M-86 and PCW boot sectors. If the geometry could be guessed, then "geom" will be initialised and DSK_ERR_OK will be returned. If no guess could be made, then DSK_ERR_BADFMT will be returned. Other values will result if the disc could not be read.

Some drivers (in particular the MYZ80 driver, and the Win32 driver under NT) only support certain fixed disc geometries. In this case, the geometry returned will reflect what the driver can use, rather than what the boot sector says.

4.19 dg_*geom : Initialise disc geometry from boot sector

```
dsk_err_t dg_dosgeom(DSK_GEOMETRY *self, const unsigned char *bootsect)
dsk_err_t dg_pcwgeom(DSK_GEOMETRY *self, const unsigned char *bootsect)
dsk_err_t dg_cpm86geom(DSK_GEOMETRY *self, const unsigned char *bootsect)
dsk_err_t dg_aprigeom(DSK_GEOMETRY *self, const unsigned char *bootsect)
```

These functions are used by `dsk_getgeom()`, but can also be called independently. Enter them with:

- “self” is the structure to initialise;
- “bootsect” is the boot sector to initialise the structure from.

Returns `DSK_ERR_BADFMT` if the sector does not contain a suitable disc specification, or `DSK_ERR_OK` otherwise.

dg_dosgeom will check for a PC-DOS boot sector.

dg_pcwgeom will check for an Amstrad PCW boot sector.

dg_cpm86geom will check for a CP/M-86 boot sector.

dg_aprigeom will check for an Apricot DOS boot sector.

4.20 dg_stdformat : Initialise disc geometry from a standard LibDsk format.

```
dsk_err_t dg_stdformat(DSK_GEOMETRY *self, dsk_format_t formatid, dsk_cchar
```

Initialises a `DSK_GEOMETRY` structure with one of the standard formats LibDsk knows about. Formats are:

FMT_180K: 180k, 9 512 byte sectors, 40 tracks, 1 side

FMT_200K: 200k, 10 512 byte sectors, 40 tracks, 1 side

FMT_CPCSYS: Amstrad CPC system format - as `FMT_180K`, but physical sectors are numbered 65-73

FMT_CPCDATA: Amstrad CPC data format - as `FMT_180K`, but physical sectors are numbered 193-201

FMT_720K: 720k, 9 512 byte sectors, 80 tracks, 2 sides

FMT_800K: 800k, 10 512 byte sectors, 80 tracks, 2 sides

FMT_1440K: 1.4M, 18 512 byte sectors, 80 tracks, 2 sides

FMT_160K: 160k, 8 512 byte sectors, 40 tracks, 1 side

FMT_320K: As `FMT_160K`, but 2 sides

FMT_360K: As `FMT_180K`, but 2 sides

FMT_720F: As `FMT_720K`, but the physical/logical sector mapping is “out-and-back” rather than “alternate sides”. See section 3.1.1 for details.

FMT_1200F: As `FMT_720F`, but with 15 sectors

FMT_1440F: As `FMT_720F`, but with 18 sectors

FMT_ACORN160: Acorn 40 track single sided 160k (used by ADFS ‘S’ format)

FMT_ACORN320: Acorn 80 track single sided 320k (used by ADFS 'M' format)

FMT_ACORN640: Acorn 80 track double sided 640k (used by ADFS 'L' format)

FMT_ACORN800: Acorn 80 track double sided 800k (used by ADFS 'D' and 'E')

FMT_ACORN1600: Acorn 80 track high density 1600k (used by ADFS 'F' format)

FMT_BBC100 BBC micro 40 track single sided 100k (using FM encoding)

FMT_BBC200 BBC micro 80 track single sided 200k (using FM encoding)

FMT_MBEE400 Microbee 40 track double sided 400k

FMT_MGT800 MGT 80 track double sided 800k (used by MGT +D and Sam Coupé).

If the “fname” is not NULL, it will be pointed at a short name for the format (suitable for use as a program option; see `tools/dskform.c`).

If the “fdesc” is not NULL, it will be pointed at a description string for the format. With these two, it's possible to enumerate geometries supported by the library without keeping a separate list in your program - see `tools/formnames.c` for example code that does this.

If additional formats have been specified in the `libdiskrc` file (section 5.1), they will be returned by this function, using format numbers starting at the last builtin format plus 1.

4.21 `dsk_*_forcehead`: Override disc head

```
dsk_err_t dsk_set_forcehead(DSK_PDRIIVER self, int force)
dsk_err_t dsk_get_forcehead(DSK_PDRIIVER self, int *force)
```

(This function is deprecated; it is equivalent to `dsk_set_option()` / `dsk_get_option()` with “HEAD” as the option name).

Forces the driver to ignore the head number passed to it and always use either side 0 or side 1 of the disc. This is used to read discs recorded on PCW / CPC / Spectrum+3 add-on 3.5" drives. Instead of the system software being programmed to use both sides of the disc, a switch on the drive was used to set which side was being used. Thus discs would end up with both sides saying they were head 0.

Anyway, when using `dsk_set_forcehead`, pass:

-1: Normal - the head passed as a parameter to other calls is used.

0: Always use side 0.

1: Always use side 1.

4.22 `dsk_*_option`: Set/get driver option

```
dsk_err_t dsk_set_option(DSK_PDRIIVER self, const char *name, int value)
dsk_err_t dsk_get_option(DSK_PDRIIVER self, const char *name, int *value)
```

Sets or gets a driver-specific numeric option.

The “name” field is the option name. If the selected driver does not support the appropriate option, then the error DSK_ERR_BADOPT will be returned. If the option is valid but the value requested is not, DSK_ERR_BADVAL will be returned.

The following driver options are supported by the Linux and NTWDM floppy drivers:

HEAD Force the drive always to use one or other side of the disc, ignoring the disc geometry. Valid values are 0 or 1 to force one or other side of the disc, -1 to allow either.

DOUBLESTEP To support a 48tpi disc in a 96tpi drive, double all cylinder numbers. Valid values are 1 (enable) or 0 (disable).

ST0 / ST1 / ST2 / ST3 These are the values of the floppy controller’s 4 status registers returned by the last operation. They cannot be changed, only read.

The ‘remote’ driver supports the following option (plus any options that the remote driver supports):

REMOTE:TESTING This disables an optimisation in the remote driver, so that it sends method calls to the remote server even if it has been asked not to. The purpose of this is to ensure that all calls to the remote driver result in RPC packets being sent.

4.23 dsk_option_enum: Get list of driver options

```
dsk_err_t dsk_option_enum(DSK_PDIVER self, int idx, char **optname)
```

If “idx” is in the range 0 -> number of driver options, (*optname) is set to the name of the appropriate driver option. If not, (*optname) is set to NULL.

4.24 dsk_*_comment: Set comment for disc image

```
dsk_err_t dsk_set_comment(DSK_PDIVER self, const char *comment)
dsk_err_t dsk_get_comment(DSK_PDIVER self, char **comment)
```

Used to get or set the comment (if any) for the current disc. Comments are only supported by the ApriDisk format; you can set a comment for other file types but it will not be saved. The pointer passed or returned may be NULL (meaning “No comment”).

4.25 dsk_type_enum

```
dsk_err_t dsk_type_enum(int index, char **drvname)
```

If “index” is in the range 0 -> number of LibDisk drivers, (*drvname) is set to the short name for that driver (eg: “myz80” or “raw”). If not, (*drvname) is set to NULL.

4.26 dsk_comp_enum

```
dsk_err_t dsk_comp_enum(int index, char **compname)
```

As `dsk_type_enum()`, but lists supported compression schemes.

4.27 dsk_drvname, dsk_drvdesc

```
const char *dsk_drvname(DSK_PDRIVER self)
const char *dsk_drvdesc(DSK_PDRIVER self)
```

Returns the driver name (eg: “myz80”) or description (eg “MYZ80 hard drive driver”) for an open disc image.

4.28 dsk_compname, dsk_compdesc

```
const char *dsk_compname(DSK_PDRIVER self);
const char *dsk_compdesc(DSK_PDRIVER self);
```

Returns the compression system name (eg: “gz”; NULL if the disc image isn’t compressed) or description (eg: “GZip compressed”) for an open disc image.

4.29 dg_ps2ls, dg_ls2ps, dg_pt2lt, dg_lt2pt

Convert between logical sectors and physical cylinder/head/sector addresses. Normally these functions are called internally and you don’t need to use them.

```
dsk_err_t dg_ps2ls(const DSK_GEOMETRY *self, dsk_pcytl_t cyl, dsk_phead_t head,
```

Converts physical C/H/S to logical sector.

```
dsk_err_t dg_ls2ps(const DSK_GEOMETRY *self, dsk_lsect_t logical, dsk_pcytl_t cyl,
```

Converts logical sector to physical C/H/S.

```
dsk_err_t dg_pt2lt(const DSK_GEOMETRY *self, dsk_pcytl_t cyl, dsk_phead_t head,
```

Converts physical C/H to logical track.

```
dsk_err_t dg_lt2pt(const DSK_GEOMETRY *self, dsk_ltrack_t logical, dsk_pcytl_t cyl,
```

Converts logical track to physical C/H.

4.30 dsk_strerror: Convert error code to string

```
char *dsk_strerror(dsk_err_t err)
```

Converts an error code returned by one of the other LibDsk functions into a printable string.

4.31 dsk_reportfunc_set / dsk_reportfunc_get

```
void dsk_reportfunc_set(DSK_REPORTFUNC report, DSK_REPORTEND repend);  
void dsk_reportfunc_get(DSK_REPORTFUNC *report, DSK_REPORTEND *repend);
```

Used to set callbacks from LibDsk to your own code, for LibDsk to display messages during processing that may take time. The code should be used to set the text on the status line of your program window, for example.

```
typedef void (*DSK_REPORTFUNC)(const char *message);  
typedef void (*DSK_REPORTEND)(void);
```

The first function you provide will be called when LibDsk wants to display a message (such as “Decompressing...”). The second will be called when the processing has finished.

4.32 dsk_set_retry / dsk_get_retry

```
dsk_err_t dsk_set_retry(DSK_PDRIVER self, unsigned int count);  
dsk_err_t dsk_get_retry(DSK_PDRIVER self, unsigned int *count);
```

Sets the number of times that a failed read, write, check or format operation will be attempted. 1 means “only try once, do not retry”.

4.33 dsk_get_psh

```
unsigned char dsk_get_psh(size_t sector_size)
```

Converts a sector size into the sector shift used by the uPD765A controller (eg: 128 -> 0, 256 -> 1, 512 -> 2 etc.) You should not need to use this. The reverse operation is: $\text{sectorsize} = (128 \ll \text{psh})$.

4.34 Structure: DSK_FORMAT

This structure is used to represent a sector header. It has four members:

fmt_cylinder: Cylinder number.

fmt_head: Head number.

fmt_sector: Sector number.

fmt_secsz: Sector size in bytes.

4.35 LibDsk errors

DSK_ERR_OK: No error.

DSK_ERR_BADPTR: A null or otherwise invalid pointer was passed to a LibDsk routine.

DSK_ERR_DIVZERO: Division by zero: For example, a DSK_GEOMETRY is set to have zero sectors.

DSK_ERR_BADPARM: Bad parameter (eg: if a DSK_GEOMETRY is set up with `dg_cylinders = 40`, trying to convert a sector in cylinder 65 to a logical sector will give this error).

DSK_ERR_NODRVR: Requested driver not found in `dsk_open()` / `dsk_creat()`.

DSK_ERR_NOTME: Disc image could not be opened by requested driver.

DSK_ERR_SYSERR: System call failed. `errno` holds the reason.

DSK_ERR_NOMEM: `malloc()` failed to allocate memory.

DSK_ERR_NOTIMPL: Function is not implemented (eg, this driver doesn't support `dsk_xread()`).

DSK_ERR_MISMATCH: In `dsk_lcheck()` / `dsk_pcheck()`, sectors didn't match.

DSK_ERR_NOTRDY: Drive is not ready.

DSK_ERR_RDONLY: Disc is read-only.

DSK_ERR_SEEKFAIL: Seek fail.

DSK_ERR_DATAERR: Data error.

DSK_ERR_NODATA: Sector ID found, but not sector data.

DSK_ERR_NOADDR: Sector not found at all.

DSK_ERR_BADFMT: Not a valid format.

DSK_ERR_CHANGED: Disc has been changed unexpectedly.

DSK_ERR_ECHECK: Equipment check.

DSK_ERR_OVERRUN: Overrun.

DSK_ERR_ACCESS: Access denied.

DSK_ERR_CTRLR: Controller failed.

DSK_ERR_COMPRESS: Compressed file is corrupt.

DSK_ERR_RPC: Error in remote procedure call.

DSK_ERR_BADOPT: Driver does not support the requested option.

DSK_ERR_BADVAL: Driver does support the requested option, but the passed value is out of range.

DSK_ERR_UNKNOWN: Unknown error

4.36 Miscellaneous

LIBDSK_VERSION is a macro, defined as a string containing the library version - eg "1.0.0"

5 Initialisation files

In addition to its built-in library of formats, LibDsk can also load formats from one or two external files - a systemwide file (libdiskrc) and a user-specific file (.libdiskrc). The rules for how these files are found differ from platform to platform.

5.1 libdiskrc format

The file format is similar to a Windows .INI file. Each format is described in a section, which starts with the format name in square brackets (format names may not start with a hyphen). After the format name, there are a number of lines of the form variable=value.

Anything after a semicolon or hash character is treated as a comment and ignored. Blank lines are also ignored.

For each geometry, the entries listed below can be present. If not all the values are present, LibDsk will use default values from its "pcw180" format. As you can see, they correspond to members of the DSK_GEOMETRY structure.

description=DESC The description of the format as shown by (for example) dskform -help.

sides=TREATMENT How a double-sided disk is handled. This can either be *alt* (sides alternate – used by most PC-hosted operating systems), *outback* (use side 0 tracks 0-79, then side 1 tracks 79-0 – used by 144FEAT CP/M disks), or *outout* (use side 0 tracks 0-79, then side 1 tracks 0-79 – used by some Acorn formats). If the disk is single-sided, this parameter can be omitted.

cylinders=COUNT Sets the number of cylinders (usually 40 or 80).

heads=COUNT Sets the number of heads (usually 1 or 2 for single- or double- sided).

sectors=COUNT Sets the number of sectors per track.

secbase=NUMBER Sets the first sector number on a track. Usually 1; some Acorn formats use 0.

secsize=COUNT Sets the size of a sector in bytes. This should be a power of 2.

datarate=VALUE Sets the rate at which the disk should be accessed. This is one of *HD*, *DD*, *SD* or *ED*.

rwgap=VALUE Sets the read/write gap.

fmtgap=VALUE Sets the format gap.

fm=Y or N Sets the recording mode - Y for FM, N for MFM.

multitrack=Y or N Sets multitrack mode.

skipdeleted=Y or N Sets whether to skip deleted data.

5.1.1 libdiskrc example

```
; This is FMT_800K as a libdiskrc entry
[xcf2dd]
Description = 800k XCF2DD format
Sides = Alt
Cylinders = 80
Heads = 2
Sectors = 10
SecBase = 1
SecSize = 512
DataRate = SD
RWGap = 12
FmtGap = 23
[xcf2]
Description = 200k XCF2 format
Cylinders = 40
```

... etc.

5.2 Locating libdiskrc

5.2.1 UNIX

The systemwide file is located at `${datadir}/LibDsk/libdiskrc`. The `${datadir}` is usually `/usr/local/share`; you can change it with the `--datadir` or `--prefix` arguments to the configure script.

The user-specific file is `$(HOME)/.libdiskrc`.

5.2.2 Win32

The systemwide file is in the path specified at

```
HKEY_LOCAL_MACHINE\Software\jce@seasip\LibDsk\ShareDir
```

If this registry key is not found, LibDsk finds the path of the program that called it (using `GetModuleFileName()`), and then uses `"../program path../share/libdiskrc"`.

The user-specific file is in the path specified at

```
HKEY_CURRENT_USER\Software\jce@seasip\LibDsk\HomeDir
```

If this registry key is not present, the user's "My Documents" directory is used. Either way, the file is called `.libdiskrc`.

5.2.3 Win16

The systemwide file is found from the location of the calling program using `GetModuleFileName()`. There is no user-specific file.

5.2.4 DOS

The systemwide file is only searched for if the LIBDSK environment variable is set; if it is set, it is assumed to be the name of the directory containing libdiskrc. There is no user-specific file.

6 Reverse CP/M-FS (rcpmfs) backend

The rcpmfs backend is designed to present a host directory as a read/write CP/M disk image. This has a number of uses:

- You could construct a CP/M disk image using `dsktrans directory filename`.
- Conversely, you could extract the files from a CP/M disk image using `dsktrans filename directory`.
- It is possible for a CP/M emulator running a genuine copy of CP/M to use LibDsk to access files on the host system, without altering the BDOS or installing additional drivers.

rcpmfs does not work with systems that only support “8.3” format filenames; it also needs a system call that can set the size of a file (such as `truncate()` under UNIX). It therefore remains unimplemented in the DOS and Win16 versions of the library.

6.1 In Use

To use an rcpmfs directory in LibDsk, pass a directory name instead of a filename. Files in the directory which match CP/M naming conventions (8.3 filenames) will appear in the emulated disk image; if there are more files than will fit in the emulated disk, LibDsk will stop when it reaches one that doesn’t fit. Under Windows, the ‘short filename’ is used, so files with names not matching CP/M conventions may also be mapped with names like `README~1.HTM`.

CP/M has 16 user areas (some variants support 32; rcpmfs does not), and files with the same name can exist in each area. rcpmfs represents nonzero user areas by prepending “nn.” to the filename; so if a CP/M program created a file called `EXAMPLE.DAT` in user 4, this would be saved as “04..example.dat” in the underlying directory. The double dot ensures that the resulting filename is not a valid CP/M name, and therefore won’t conflict with any file in user 0.

rcpmfs can behave as a CP/M 2 or CP/M 3 filesystem. If the latter, it constructs a disc label (based on the name of the directory) and turns on date/time stamping. Update and access stamps are used, because they map nicely to the `utime()` system call.

6.2 rcpmfs initialisation file

For a directory to be usable by rcpmfs, it should contain a file called `.libdisk.ini` describing the format to use. This file is in INI format, similar to `libdiskrc` (section 5.1). It must contain only one section: `[RCPMFS]`. Within that section, the following variables may be present:

BlockSize Size of a CP/M data block. Must be a power of 2, and at least 1024. If there are more than 255 blocks in the CP/M filesystem, this must be at least 2048.

DirBlocks Number of blocks containing the CP/M directory.

TotalBlocks Total number of data and directory blocks.

SysTracks Number of system tracks. These will be stored in a file called `.libdisk.boot`.

Version CP/M version that will be accessing the filesystem - either 2 or 3. Setting it to 2 should disable time stamps and disk labels.

Format Name of one of the LibDsk built-in or user-supplied formats, giving the geometry that the simulated disk will have. Alternatively, you can specify the format manually, using the same variable names as in `libdiskrc`.

If there is no `.libdisk.ini` file present, LibDsk will assume `BlockSize=1024`, `DirBlocks=2`, `TotalBlocks=175`, `SysTracks=1`, `Version=3`, `Format=pcw180`.

6.3 Bugs

`rcpmfs` is new and untried code. The following are known bugs or missing features:

- So far, `rcpmfs` has only been tested under the `dsktrans` pattern of usage (which writes the directory and then the file space), and with fairly simple operations in a CP/M emulator. It is not known how well it holds up under heavy use as a live CP/M filesystem.
- The CP/M attributes F1-F4, passwords and permissions are not mapped. The SYS and ARC attributes are only mapped in the Win32 version.
- Formatting (or reformatting) an `rcpmfs` directory writes out a new `.libdisk.ini` containing the geometry used to do the format. However, since `DSK_GEOMETRY` doesn't contain the CP/M filesystem parameters (block size, block count, etc.) these will be the ones previously used in that directory, and quite possibly completely wrong. It's a much better idea to 'format' the directory using means other than LibDsk.

7 The CopyQM file format

7.1 Introduction

This section describes the file format of files created by CopyQM. A lot of the information has been extracted by looking at hex-dumps of the files, so there might be some errors in the description.

7.2 Header

The CopyQM files consist of a header, an optional comment (if indicated by the header) followed by the tracks of the image encoded with a run length encoding scheme. The header is 133 bytes long, see table. It always starts with `{0x43, 0x51, 0x14 }`, which can be used for auto-detection of the image. All numbers have little-endian byte ordering. When all bytes in the header are added together in a byte, the result should be zero.

| Offset | Size | Comment |
|--------|------|--|
| 0x00 | 1 | Always 0x43 ('C') |
| 0x01 | 1 | Always 0x51 ('Q') |
| 0x02 | 1 | Always 0x14 |
| 0x03 | 2 | Sector size |
| 0x0b | 2 | Total number of sectors. (DOS) |
| 0x10 | 2 | Number of sectors per track |
| 0x12 | 2? | Number of heads |
| 0x1c | 60? | Description (e.g. "0K Double-Sided") |
| 0x58 | 1 | Type of image. 0=blind, 1=DOS, 2=HFS |
| 0x59 | 1 | Density. 0=DD, 1=HD, 2=ED |
| 0x5a | 1 | Number of tracks used on image |
| 0x5b | 1 | Total number of tracks for image |
| 0x5c | 4 | CRC for the used, unpacked tracks |
| 0x60 | 11 | Volume label (DOS/HFS) |
| 0x6b | 2 | Creation time |
| 0x6d | 2 | Creation date |
| 0x6f | 2 | Length of image comment |
| 0x71 | 1 | Number of first sector - 1 |
| 0x74 | 1 | Interleave. (0 for older versions of CopyQM) |
| 0x75 | 1 | Skew. Normally 0. Negative number for alt. sides |
| 0x84 | 1 | Header checksum byte |

7.3 CRC

The CRC is calculated for the unpacked data for all tracks that are used in the image. The CRC value is initialized with 0 and then updated using the CRC 32 polynomial 0x104C11DB7, bit reverse algorithm. Due to a feature in CopyQM (8 bit register as an index into a 1024 byte table) all bytes must have their top two bits removed before added to the CRC.

7.4 Image comment

The image comment follows the header. It has a variable size found in the header. The image comment can contain \0-bytes.

7.5 Image data

The image data is run length encoded. Each run is preceded by a 16-bit length. If the length is negative, the byte after the length is repeated **-length** times. If the length is positive, it is followed by **length** bytes of unencoded data. It seems like a new run of repeating or differing data is always started at each new track. Older versions of CopyQM always alternates between runs of differing data and repeating data, even if the length of one of them is zero.

8 LibDsk under Windows

This section mainly deals with the subject of direct floppy drive access. Other aspects of LibDsk remain relatively consistent across Windows versions.

As with so many other aspects of Windows, direct access to the floppy drive is a case of “write once - debug everywhere”¹. Not only does support vary across different systems, it varies depending on whether LibDsk was compiled with a 16-bit compiler or a 32-bit one. This table shows the different possibilities and the resulting behaviour:

| Windows Version | Win16 Subsystem | Win32 Subsystem |
|-------------------------|----------------------|-----------------|
| 3.x | Fairly good | n/a |
| 4.x (95, 98 and ME) | Good but less stable | Limited |
| NT, 2000, XP | Very limited | |
| 2000, XP + ntwdm driver | Good | |

8.1 Windows 3.x

Only the 16-bit build of LibDsk will run. The floppy support in Win16 is pretty much the same as in DOS; there is support for discs with arbitrary numbers of tracks and sectors, and arbitrary sector sizes. This means that LibDsk can, for example, read Acorn ADFS floppies.

8.2 Windows 4.x (95, 98 and ME)

Both the 16-bit and 32-bit versions of LibDsk will run. The 16-bit version is more capable, but less stable; it can read Acorn ADFS floppies, which the 32-bit version cannot. Unfortunately, 32-bit programs can’t link to the 16-bit version of LibDsk², but there is a workaround (described below) involving the use of LDSEVER.

8.3 Windows NT (NT 3.x, NT 4.x, 2000, XP) without ntwdm driver

The floppy drive can only read/write formats which are supported by the floppy driver. This is the case using either version of LibDsk.

8.4 Windows 2000 and XP with ntwdm driver

Simon Owen’s enhancement to the Windows 2000 floppy driver can be downloaded from <<http://simonowen.com/fdrawcmd/>>. Once it is installed, LibDsk (using its ‘ntwdm’ driver rather than ‘floppy’) has pretty much carte blanche regarding floppy formats, and can access discs in many formats including Acorn ADFS.

8.5 General comments on programming floppy access for Windows

LibDsk has four independent drivers for accessing floppies under Windows. They are:

8.5.1 The Win16 driver.

This uses INT 0x13 to do the reads and writes, just as in MSDOS. Again as in MSDOS, there is a diskette parameter table pointed to by INT 0x1E. This table seems not to be documented, which is perhaps why the Win16 subsystem in Windows 2000/XP doesn’t implement it. You can, fortunately, tell if this is the case; if the first two bytes are both

¹Originally said by Microsoft with respect to Java. Pot. Kettle. Black.

²And no, the Generic Thunk isn’t good enough. I’ve tried it.

0xC4, then what you have is a Windows 2000 trap rather than a diskette parameter table.

8.5.2 The Win32c driver.

This driver uses VWIN32 services to make INT 0x13-style calls under Windows9x. However, there is no VWIN32 call to change the diskette parameter table, which is why the Win16 driver can do things the Win32 drivers can't. It isn't possible to get round this by thunking to a 16-bit DLL either; the INT 0x1E vector is zero for 16-bit DLLs in 32-bit processes.

8.5.3 The Win32 driver.

Windows NT gets close (but not close enough) to the UNIX idea that everything is a file. So while in theory it would be enough to use the normal "raw" driver on "\\.\A:", in practice there are a number of nasty subtleties relating to such things as memory alignment and file locking.

8.5.4 The ntwdm driver.

This driver is a wrapper around fdrawcmd.sys, which allows commands to be issued to the floppy controller.

8.5.5 Other floppy APIs

Sydex produce a replacement floppy driver for 32-bit versions of Windows (SydexFDD) which is not supported by LibDsk.

8.6 LDSERVER

LDSERVER is a program that makes the 16-bit LibDsk DLL available to 32-bit programs. It does this by creating a mailslot ("\\.\mailslot\LibDsk16") and listening for messages. Each message corresponds to a LibDsk call.

The 32-bit LibDsk library checks for this mailslot and, if it finds it, uses it in preference to its own floppy support.

8.6.1 Compiling LDSERVER

A compiled version of LDSERVER is not supplied. You will need to build it yourself from the files in the rpcserv directory; projects are provided for Microsoft Visual C++ 1.5 and Borland C++ 5.0.

LDSERVER calls functions in NETAPI.DLL. If your compiler doesn't include an import library for this DLL, you will have to generate it using the IMPLIB tool - eg:

```
IMPLIB NETAPI.LIB NETAPI.DLL
```

or the equivalent utility for your compiler.

8.6.2 Using LDSERVER

Just run LDSERVER.EXE, and then use a 32-bit LibDsk program. The server window shows a reference count (0 if it is idle, nonzero if LibDsk programs are using it) and the status should change to “Active” when it is performing disc access.

LDSERVER does not shut down automatically.

8.6.3 Important Security Warning

LDSERVER is a 16-bit program, written using APIs intended for use on a local area network. These APIs have no security support. It will happily obey commands sent from anywhere on your network. If your computer is connected to the Internet, it will obey commands sent to it over the Internet. A malicious attacker could use LDSERVER to overwrite important system files or read confidential documents.

If you have a firewall, then make sure that the NetBIOS ports 137, 138 and 139 are blocked. If you don't have a firewall, ***do not run LDSERVER while your computer is connected to the Internet!***

8.7 LibDsk and COM

If you are building the 32-bit version of LibDsk with Visual C++ 6.0, you can also build the accompanying 'atlibdsk' project, which builds a version of LibDsk that exports its API through COM. This allows relatively easy use of LibDsk from languages that support COM binding, such as Visual BASIC or .NET languages.

8.7.1 General points

Where LibDsk functions return a `dsk_err_t`, ATLIBDSK returns a COM HRESULT. This will be `S_OK` for success, a general COM error (such as `E_POINTER` or `E_INVALIDARG`), or a `FACILITY_ITF` error (`0x8004xxxx`). The low word of a `FACILITY_ITF` error is the LibDsk error code, converted to a positive number (eg: `0x8004000C` is `FACILITY_ITF` error 12, so the LibDsk error is -12, `DSK_ERR_SEEKFAIL`).

Sector buffers to be read/written must be passed as variants containing arrays of bytes.

The arrays of `DSK_FORMAT` structures passed to `dsk_lform()` and `dsk_pform()` are replaced by variants containing arrays of bytes - four bytes per sector to format. The last byte is the physical sector shift (0 for 128, 1 for 256 etc.)

ATLIBDSK exports four object classes:

8.7.2 Library

This contains LibDsk functions not associated with a particular disk image. Its methods are:

| Method | Equivalent LibDsk call | Comments |
|-----------------|--------------------------|--|
| open | dsk_open | Instantiates a new Disk object. |
| create | dsk_creat | Instantiates a new Disk object. |
| get_psh | dsk_get_psh | |
| dosgeom | dg_dosgeom | Instantiates a new Geometry object. |
| cpm86geom | dg_cpm86geom | Instantiates a new Geometry object. |
| pcwgeom | dg_pcwgeom | Instantiates a new Geometry object. |
| apriggeom | dg_apriggeom | Instantiates a new Geometry object. |
| stdformat | dg_stdformat | Instantiates a new Geometry object. |
| stdformat_count | | Returns the number of formats supported by stdformat |
| type_enum | dsk_type_enum | Returns TRUE if the passed index is valid, else FALSE. |
| comp_enum | dsk_comp_enum | Returns TRUE if the passed index is valid, else FALSE. |
| reporter | dsk_reportfunc_{set,get} | This is a property of type IReporter |

8.7.3 Geometry

This corresponds to the DSK_GEOMETRY structure. The following properties correspond to the structure members:

- sidedness
- cylinders
- heads
- sectors
- secbase
- datarate
- secsize
- rwgap
- fmtgap
- fm
- nomulti
- noskip

There are also five functions. Four are for logical/physical sector conversions:

- ls2ps
- lt2pt
- ps2ls
- pt2lt

and the last is stdformat(), which wraps dg_stdformat().

8.7.4 Disk

The Disk object corresponds to a LibDsk DSK_PDRIVER value. You should not create one yourself (method calls will fail with E_POINTER) but call the 'create' or 'open' methods of the Library object.

Functions included are:

- get_geometry
- close
- drive_status
- pread
- lread
- xread
- pwrite
- lwrite
- xwrite
- pcheck
- lcheck
- xcheck
- pformat
- lformat
- apform
- alform
- ptread
- ltread
- xtread
- psecid
- lsecid
- lseek
- pseek
- option_enum

all of which are pretty similar to their LibDsk namesakes. There are also the following properties:

- comment

- option
- retries
- drvname
- drvdesc
- compname
- compdesc

8.7.5 IReporter

IReporter is used for the LibDsk message callback. It is an interface that should be implemented by an object in your program. Set the library's "reporter" property to your object; then its report() and endreport() methods will be called.

9 LibDsk RPC system

The LibDsk RPC system is designed to make disc drives on remote computers transparently available to LibDsk applications. It operates on a client/server basis; LibDsk contains a driver (called 'remote') that can act as a client, and it can be used to implement a server.

The on-the-wire protocol is described in protocol.txt in the documentation directory.

9.1 The 'serial' driver

This is designed for using LibDsk over a serial connection - say from a 3.5" computer to a 5.25" computer. The filename specification to use at the client end is:

```
serial:port,baud,remotename{,remotetype{,remotecompress}}
```

for example:

```
serial:/dev/ttyS0,9600+crtscs,A:
```

The various parts of this filename specification are:

port The local serial port to use.

- Under Linux, this is the name of a serial port (eg /dev/ttyS0).
- Under Windows, this is likewise the name of a serial port (eg COM1:).
- Under DOS, you need to have a FOSSIL serial port driver loaded; LibDsk was tested using ADF <http://ftp.iis.com.br/pub/simtelnet/msdos/fossil/adf_150.zip> (or do a web search for adf_150.zip). The port is then the number assigned by the FOSSIL driver (normally 0). Note also that ADF uses a single fixed baud rate, so you should make sure that the rate on the command line matches the rate that was used when ADF was loaded.

baud The speed and handshaking options. LibDsk does not allow the number of bits, the parity or the count of stop bits to be changed; it insists on 8-bit communications with 1 stop bit and no parity. The speed is a number (300, 600, 1200 etc.) and the handshake option is “+crtsets” (to use RTS/CTS handshaking) or “-crtsets” (not to). If neither handshake option is present, “+crtsets” is assumed.

remotename The name of the file or drive on the remote computer.

remotetype The type of the file/drive (“dsk”, “floppy” etc.).

remotecompress The compression to use on the remote computer.

9.1.1 Servers for the serial driver

One of the sample utilities supplied with LibDsk is called serslave (serslave.exe under DOS / Windows). This is a server using the same serial protocol as above.

Launch serslave with the command:

```
serslave port,baud
```

for example:

```
serslave COM1:,9600+crtsets
```

or in DOS (again, a FOSSIL driver is required):

```
serslave 0,19200
```

I have written a similar server for CP/M systems, called AUXD. This is a separate download from the LibDsk web page.

9.2 The ‘fork’ driver

The ‘fork’ driver is used (on any system which supports the fork() system call) to send LibDsk requests to a local program using pipes. This driver was written for testing purposes, but may come in handy as a poor man’s plugin system. The filename specification is:

```
fork:program,remotename{,remotetype{,remotecompress}}
```

for example:

```
fork:./dskslave,a.dqk,dsk,sq
```

The various parts of this filename specification are:

program The name of the program to use; execlp() is used to launch it, so if no path is given the user’s PATH will be searched. The program must take LibDsk calls from its standard input and send results to its standard output.

remotename The name of the file or drive.

remotetype The type of the file/drive (“dsk”, “floppy” etc.).

remotecompress The compression to use.

An example of a server for this protocol is the example ‘forkslave’ program; this is a very simple wrapper around dsk_rpc_server() which reads RPC packets from its standard input and writes them to its standard output.

10 Writing new drivers

The interface between LibDsk and its drivers is defined by the `DRV_CLASS` structure. To add a new driver, you create a new `DRV_CLASS` structure and add it to various files.

10.1 The driver header

Firstly, create a header for this driver, basing it on (for example) `lib/drvposix.h`. The first thing in the header (after the LGPL banner) is:

```
typedef struct
{
    DSK_DRIVER px_super;
    FILE *px_fp;
    int px_readonly;
    long px_filesize;
} POSIX_DSK_DRIVER;
```

This is where you define any variables that your driver needs to store for each disc image. In the case of the “raw” driver, this consists of a `FILE` pointer to access the underlying disc file, a “readonly” flag, and the current size of the drive image file. The first member of this structure must be of type `DSK_DRIVER`.

The rest of this header consists of function prototypes, which I will come back to later.

10.2 The driver source file

Secondly, create a `.c` file for your driver. Again, it’s probably easiest to base this on `lib/drvposix.c`. At the start of this file, create a `DRV_CLASS` structure, such as:

```
DRV_CLASS dc_posix =
{
    sizeof(POSIX_DSK_DRIVER),
    "raw",
    "Raw file driver",
    posix_open,
    posix_creat,
    posix_close
};
```

The first three entries in this structure are:

- The size of your driver’s instance data;
- The driver’s name (as passed to `dsk_open()` / `dsk_creat()`)
- The driver’s description string.

The remainder of the structure is composed of function pointers; the types of these are given in `drv.h`. At the very least, you will need to provide the first three pointers (`*_open`, `*_creat` and `*_close`); to make the driver vaguely useful, you will also need to implement some of the others.

Once you have created this structure, edit:

- `drivers.h`. Add a declaration for your `DRV_CLASS` structure, such as

```
extern DRV_CLASS dc_myformat;
```

- `drivers.inc`. Insert a reference to your structure (eg: `&dc_myformat,`) in the list. Note that order is important; the comments in `drivers.inc` describe how to decide where things go.

Edit `lib/Makefile.am`. Near the top of this file is a list of drivers and their header files; just add your `.c` and `.h` to this list.

If your driver depends on certain system headers (as all the floppy drivers do) then you will need to add checks for these to `configure.in` and `lib/drv.h`; then run `autoconf` to rebuild the configure script.

The function pointers in the `DRV_CLASS` structure are described in `drv.h`. The first parameter to all of them (`self`) is declared as a pointer to `DSK_DRIVER`. In fact, it is a pointer to the first member of your instance data structure. Just cast the pointer to the correct type:

```
/* Sanity check: Is this meant for our driver? */
if (self->dr_class != &dc_posix) return DSK_ERR_BADPTR;
pxself = (POSIX_DSK_DRIVER *)self;
```

and you're in business.

10.3 Driver functions

10.3.1 `dc_open`

```
dsk_err_t (*dc_open)(DSK_PDRIVER self, const char *filename)
```

Attempt to open a disc image. Entered with:

- `self` points to the instance data for this disc image (see above); it will have been initialised to zeroes using `memset()`.
- `filename` is the name of the image to open.

Return:

DSK_ERR_OK: The driver has successfully opened the image.

DSK_ERR_NOTME: The driver cannot handle this image. Other drivers should be allowed to try to use it.

other: The driver cannot handle this image. No other drivers should be tried (eg: the image was recognised by this driver, but is corrupt).

If the file has a comment, record it here using `dsk_set_comment()`.

10.3.2 dc_creat

```
dsk_err_t (*dc_creat)(DSK_PDRIVER self, const char *filename)
```

Attempt to create a new disc image. For the “floppy” drivers, behaves exactly as `dc_open`. Parameters and results are the same as for `dc_open`, except that `DSK_ERR_NOTME` is treated like any other error.

10.3.3 dc_close

```
dsk_err_t (*dc_close)(DSK_PDRIVER self)
```

Close the disc image. This will be the last call your driver will receive for a given disc image file, and it should free any resources it is using. Whether it returns `DSK_ERR_OK` or an error, this disc image will not be used again.

10.3.4 dc_read

```
dsk_err_t (*dc_read)(DSK_PDRIVER self, const DSK_GEOMETRY *geom, void *buf,
```

Read a sector. Note that sector addresses passed to drivers are `_always_` in C/H/S format. This function has the same parameters and return values as `dsk_pread()`.

10.3.5 dc_write

```
dsk_err_t (*dc_write)(DSK_PDRIVER self, const DSK_GEOMETRY *geom, const void *buf,
```

Write a sector. This function has the same parameters and return values as `dsk_pwrite()`. If your driver is read-only, leave this function pointer NULL.

10.3.6 dc_format

```
dsk_err_t (*dc_format)(DSK_PDRIVER self, const DSK_GEOMETRY *geom, dsk_pcyt_t *p,
```

Format a track. This function has the same parameters and return values as `dsk_pformat()`. If your driver cannot format tracks, leave this function pointer NULL.

10.3.7 dc_getgeom

```
dsk_err_t (*dc_getgeom)(DSK_PDRIVER self, DSK_GEOMETRY *geom)
```

Get the disc geometry. Leave this function pointer as NULL unless either:

1. Your disc image does not allow a caller to use an arbitrary disc geometry. The two drivers which currently do this are the Win32 one, because Windows NT decides on the geometry itself and doesn't let programs change it; and the MYZ80 one, which has a single fixed geometry.

2. Your disc image file contains enough information to populate a DSK_GEOMETRY completely. `repmfs` does this.
3. You want to do an extended geometry probe including a call to the default one. The internal function `dsk_defgetgeom()` has been provided for this; it's the same as `dsk_getgeom()` but always uses the standard probe.

Returns `DSK_ERR_OK` if successful; `DSK_ERR_NOTME` or `DSK_ERR_NOTIMPL` to fall back to the standard LibDsk geometry probe; other values to indicate failure.

10.3.8 `dc_secid`

```
dsk_err_t (*dc_secid)(DSK_PDRIVER self, const DSK_GEOMETRY *geom, dsk_pcyll_
```

Read the ID of a random sector on a certain track/head, and put it in “result”. This function is primarily used to test for discs in CPC format (which have oddly-numbered physical sectors); if the disc image can't support this (eg: the “raw” or Win32 drivers) then leave the function pointer NULL.

10.3.9 `dc_xseek`

```
dsk_err_t (*dc_xseek)(DSK_PDRIVER self, const DSK_GEOMETRY *geom, dsk_pcyll_
```

Seek to a given cylinder / head. For disc images, just return `DSK_ERR_OK` if the cylinder/head are in range, or `DSK_ERR_SEEKFAIL` otherwise. For a floppy driver, only implement this function if your FDC can perform a seek by itself.

10.3.10 `dc_xread, dc_xwrite`

```
dsk_err_t (*dc_xread)(DSK_PDRIVER self, const DSK_GEOMETRY *geom, void *buf,
dsk_err_t (*dc_xwrite)(DSK_PDRIVER self, const DSK_GEOMETRY *geom, const void *
```

Read / write sector whose ID may not match its position on disc, or which is marked as deleted. Only implement this if your disc image emulates sector IDs or your floppy driver exposes this level of functionality. Currently it is only implemented in the Linux and CPCEMU drivers.

10.3.11 `dc_status`

```
dsk_err_t (*dc_status)(DSK_PDRIVER self, const DSK_GEOMETRY &geom, dsk_phea
```

Return the drive status (see `dsk_drive_status()` for the bits to return). “*result” will contain the value calculated by the default implementation; for most image file drivers, all you have to do is set the read-only bit if appropriate.

10.3.12 dc_tread

```
dsk_err_t (*dc_tread)(DSK_PDRIVER self, const DSK_GEOMETRY *geom, void *buf)
```

Read a track. You need only implement this if your floppy driver exposes the relevant functionality; if you don't, the library will use multiple calls to `dc_read()` instead. This function has the same parameters and return values as `dsk_ptread()`.

10.3.13 dc_xtread

```
dsk_err_t (*dc_xtread)(DSK_PDRIVER self, const DSK_GEOMETRY *geom, void *buf)
```

Read a track, with extended sector matching (sector headers on disc differ from physical location). This function has the same parameters and return values as `dsk_xtread()`. As with `dc_tread()`, you need only implement this function if your floppy driver has a special READ TRACK command.

10.3.14 dc_option_enum

```
dsk_err_t (*dc_option_enum)(DSK_DRIVER *self, int idx, char **optname);
```

List numerical options which your driver supports. If your driver does not support any, you need not implement this.

10.3.15 dc_option_set, dc_option_get

```
dsk_err_t (*dc_option_set)(DSK_DRIVER *self, const char *optname, int value)
dsk_err_t (*dc_option_get)(DSK_DRIVER *self, const char *optname, int *value)
```

Get or set the value of a numerical option. Again, if your driver has no settable options, this need not be implemented.

10.3.16 dc_trackids

```
dsk_err_t (*dc_trackids)(DSK_DRIVER *self, const DSK_GEOMETRY *geom, dsk_p
```

Read the IDs of all sectors on the specified track, preferably in the correct order and starting at the index hole. If you leave this function pointer as NULL, LibDsk will use a default implementation.

10.3.17 dc_rtread

```
dsk_err_t (*dc_rtread)(DSK_DRIVER *self, const DSK_GEOMETRY *geom, void *buf)
```

For future expansion. Leave this function pointer as NULL.

11 Adding new compression methods

Adding a new compression method is very similar to adding a driver, though you only have to implement four functions.

To add a new driver, you create a new `COMPRESS_CLASS` structure and add it to various files.

11.1 Driver header

This is done as for disc drivers. If you don't need any extra variables (for example, gzip and bzip2 compression don't) then you don't have to declare a new structure type - see `lib/compgz.h` for an example.

11.2 Driver implementation

Secondly, create a `.c` file for your driver. It's probably easiest to base this on `lib/compgz.c`. At the start of this file, create a `COMPRESS_CLASS` structure, such as:

```
COMPRESS_CLASS cc_gz =
{
    sizeof(COMPRESS_DATA),
    "gz",
    "Gzip (deflate compression)",
    gz_open, /* open */
    gz_creat, /* create new */
    gz_commit, /* commit */
    gz_abort /* abort */
};
```

The first three entries in this structure are:

- The size of your driver's instance data. The GZip driver has no instance data and so just uses `COMPRESS_DATA`. If it had extra data these would be in a struct called `GZ_COMPRESS_DATA`, so the size here would be `sizeof(GZ_COMPRESS_DATA)`.
- The driver's name (as passed to `dsk_open()` / `dsk_creat()`)
- The driver's description string.

The remainder of the structure is composed of function pointers. The types of these are given in `drv.h`. You must implement all four.

Once you have created this structure, edit:

- `comp.h`. Include your header.
- `compress.inc`. Insert a reference to your structure (eg: `"&cc_myzip,"`) in the list. Note that order is important.

Edit `"lib/Makefile.am"`. At the bottom of this file is a list of drivers and their header files; just add your `.c` and `.h` to this list.

If your driver depends on certain system headers (eg, the gzip one depends on `zlib.h`) then you will need to add checks for these to `"configure.in"` and `"lib/comp.h"`; then run `"autoconf"` to rebuild the configure script.

The function pointers in the COMPRESS_CLASS structure are described in lib/compress.h. The first parameter to all of them (“self”) is declared as a pointer to COMPRESS_DATA. In fact, it is a pointer to the first member of your instance data structure. Just cast the pointer to the correct type:

```
/* Sanity check: Is this meant for our driver? */
if (self->cd_class != &cc_sq) return DSK_ERR_BADPTR;
sqself = (SQ_COMPRESS_DATA *)self;
```

and you’re in business.

11.3 Compression functions

11.3.1 cc_open

```
dsk_err_t (*cc_open) (COMPRESS_DATA *self)
```

Attempt to decompress a compressed file.

- “self” points to the instance data for this disc image.
- self->cd_cfilename is the filename of the file to decompress.

Return:

DSK_ERR_OK: The file has been decompressed.

DSK_ERR_NOTME: The file is not compressed using this driver’s method.

other: The file does belong to this driver, but it is corrupt or some other error occurred.

Two helper functions may be useful when you are writing cc_open:

```
dsk_err_t comp_fopen (COMPRESS_DATA *self, FILE **pfp);
```

Open the the file whose name is given at self->cd_cfilename. If successful, *pfp will be the opened stream. If not, it will be NULL. If the file can only be opened read-only, sets self->cd_readonly to 1.

```
dsk_err_t comp_mktemp (COMPRESS_DATA *self, FILE **pfp);
```

Create a temporary file and store its name at self->cd_ufilename. You should use this to create the file that you decompress into.

11.3.2 cc_creat

```
dsk_err_t (*cc_creat) (COMPRESS_DATA *cd)
```

Warn the compression engine that a disc image file is being created, and when closed it will be compressed. The filename is stored at self->cd_cfilename. Normally this just returns DSK_ERR_OK.

11.3.3 cc_commit

```
dsk_err_t (*cc_commit) (COMPRESS_DATA *cd)
```

Compress an uncompressed file. `self->cd_ufilename` is the name of the file to compress. `self->cd_cfilename` is the name of the output file.

11.3.4 cc_abort

```
dsk_err_t (*cc_abort) (COMPRESS_DATA *cd)
```

This is used if a file was decompressed and it's now being closed without having been changed. There is therefore no need to compress it again. This normally just returns `DSK_ERR_OK`.

12 Adding new remote transports.

Adding a new remote transport is also very similar to adding a driver.

To add a new driver, you create a new `REMOTE_CLASS` structure and add it to various files.

12.1 Driver header

This is done as for disc drivers. Create a structure based on `REMOTE_DATA` to hold your class's data – see `lib/rpctios.h` and `lib/rpcfork.h` for examples.

12.2 Driver implementation

Create a `.c` file for your driver. It's probably easiest to base this on `lib/rpcfork.c`. At the start of this file, create a `REMOTE_CLASS` structure, such as:

```
REMOTE_CLASS rpc_fork =
{
    sizeof(FORK_REMOTE_DATA),
    "fork",
    "UNIX client using fork",
    fork_open, /* open */
    fork_close, /* close */
    fork_call, /* perform RPC */
};
```

The first three entries in this structure are:

- The size of your driver's instance data – `sizeof(your_REMOTE_DATA)` structure.
- The driver's name. If the filename passed to LibDsk begins with this name followed by a colon, then it's assumed to be using your driver.
- The driver's description string.

The remainder of the structure is composed of function pointers. The types of these are given in lib/remote.h. You must implement all three.

Once you have created this structure, edit:

- lib/remall.h. Include your header.
- lib/remote.inc. Insert a reference to your structure (eg: “&rpc_fork,”) in the list. The drivers will be tested in the order in which they appear in the file.

Edit “lib/Makefile.am”. At the bottom of this file is a list of drivers and their header files; just add your .c and .h to this list.

If your driver depends on certain system headers (eg, the termios one depends on termios.h) then you will need to add checks for these to “configure.in” and “lib/drvi.h”; then run “autoconf” to rebuild the configure script.

The function pointers in the REMOTE_CLASS structure are described in lib/compress.h. The first parameter to all of them (“pDriver”) is declared as DSK_PDRIVER; you can extract a pointer to your instance data using the dr_remote member like this:

```
/* Sanity checks */
self = (FORK_REMOTE_DATA *)pDriver->dr_remote;
if (self == NULL || self->super.rd_class != &rpc_fork)
    return DSK_ERR_BADPTR;
```

12.3 Remote communication functions

12.3.1 rc_open

```
dsk_err_t (*rc_open) (DSK_PDRIVER pDriver, const char *name, char *nameout)
```

Connect to a remote server.

- pDriver contains the pointer to our instance data.
- name is the filename as passed to LibDsk, starting with “driver:” and containing any connection parameters needed.
- nameout is an output buffer with enough space to hold a string of the same length as the input filename. If you are returning DSK_ERR_OK, it must be set to the input filename minus any options this driver has used. For example, the “serial” driver, given a filename like “serial:/dev/ttyS1,2400-crtscts,example.ufi,raw” would extract its own options and return “example.ufi,raw” here.

Return:

DSK_ERR_OK: Connection established.

DSK_ERR_NOTME: The filename passed is not recognised by this driver.

other: An error such as out-of-memory occurred.

12.3.2 rc_close

```
dsk_err_t (*rc_close) (DSK_PDRIVER pDriver)
```

Close the connection to the remote server.

12.3.3 rc_call

```
dsk_err_t (*rc_call)(DSK_PDRIVER pDriver, unsigned char *input, int inp_len)
```

Perform a remote procedure call to the server.

input is the packet LibDsk wants to send.

inp_len is the number of bytes in the packet.

output is a buffer for the result packet.

***out_len** (on entry) is the size of the result buffer.

***out_len** (on return) is the number of bytes that were populated in the result buffer.

In general, this call will wrap the input in whatever framing bytes are necessary (usually including the packet length, since packets do not contain their own length), send the packet over the wire, wait for a response, and unpack the response into 'output'. Return DSK_ERR_TIMEOUT if the connection timed out (the 'serial' driver waits 30 seconds) and DSK_ERR_ABORT if the user deliberately broke the connection.

A DQK Files

A DQK file is a .DSK file compressed using Richard Greenlaw's Squeeze file format (originally from CP/M as SQ.COM, and later built in to NSWP.COM; versions also exist for DOS and UNIX). SQ was used in preference to more efficient compressors such as gzip because it can be readily decoded on 8-bit and 16-bit computers.

The original reason for DQK files was software distribution. A disc image of a 180k disc won't fit on a 180k disc, owing to various overheads. However, the compressed DQK version may fit onto such a disc, and leave room for a tool to write the DQK back out as well.

Such a tool has been included in the "dskwrite" directory in this distribution. It contains the following files:

- dskwrite.com: Program to write .DSK or .DQK files out to a real disc. The .COM file works on PCs, Amstrad PCWs and Sinclair Spectrum +3s.
- dskwrite.txt: Documentation for dskwrite.
- dskwrite.z80: Z80 source for the CP/M version.
- dskwrite.asm: 8086 source for the DOS version.
- dskwrsea.com: The dskwrite distribution file - a self-extracting archive. It will self-extract under CP/M or DOS.

Note that the files in the "dskwrite" directory are not GPLed or LGPLed. They are public domain. You may do whatsoever you please with them.

LibDsk has been given .DQK support (use the "dsk" driver with "sq" compression) so that .DQK files don't have to be created and compressed in a two-state process.

B LibDsk with cpmtools

cpmtools v1.9 and later <<http://www.moria.de/~michael/cpmtools/>> can be configured to use LibDsk for all disc access, thus allowing CP/M discs and emulator disc images to be read and written.

The myz80 and nanowasp drivers use a fixed disk format; here are diskdefs entries which can be used to read them (these are for the old diskdefs format with one line per entry):

```
myz80      1024 64 128 4096 1024 1 0 3
microbee   512 80  10 2048 128  1 2 2.2
```

C DSK / EDSK recording mode extension

This extension was proposed by me on the comp.sys.sinclair and comp.sys.amstrad.8bit newsgroups on 10 January 2004. It was subsequently released in ANNE 2.1.4 and added to the formal EDSK format definition at <<http://andercheran.aiind.upv.es/~amstrad/docs/extdsk.html>>.

DSK/EDSK originate on the Amstrad CPC, which ordinarily writes all its diskettes in MFM recording mode and at the Double Density rate. However, ANNE emulates the PcW16, which also supports the High Density rate; and the system software depends on DD discs not being readable at the HD rate.

The extension gives meanings to two unused bytes of the DSK/EDSK “Track-Info” block:

Byte 12h: Data rate.

- 0 Unknown
- 1 Single or Double Density (180k, 720k, etc.)
- 2 High Density (1.2M, 1.4M, etc.)
- 3 Extended Density (2.8M)

Byte 13h: Recording mode.

- 0 Unknown
- 1 FM
- 2 MFM

Existing files should have zeroes in these bytes; hence the use of 0 for Unknown. LibDsk will guess the values in if the ones in the file are zero.